

# 01M Air Compressor Manual

---

## Instruction Manual



**YOUNG IL M Co., Ltd.**

7F, Starwoodplaza, 400, Dunchon-daero, Jungwon-gu, Seongnam-si, Gyeonggi-do, Republic of Korea  
Tel: +82-1544-8501, Fax: +82-31-737-0801 , Email: 01md@01m.co.kr , www.01m.co.kr

---

# 01M Air Compressor

This instructions for use document covers safe operation of the air compressor.

Additional information and resources are available upon request or directly from the website, [www.01m.co.kr](http://www.01m.co.kr)

If the needed information is not found, contact 01M directly at 01md@01m.co.kr

Thank you,

YOUNG IL M Co., Ltd.

7F, Starwoodplaza, 400, Dunchon-daero,  
Jungwon-gu, Seongnam-si, Gyeonggi-do,  
Republic of Korea

Tel: +82-1544-8501

Fax: +82-31-737-0801

Email: 01md@01m.co.kr , [www.01m.co.kr](http://www.01m.co.kr)


“Treat and Help the Treated, Bring Happiness to the Members and Society”

---

# Table of Contents

1. Components	-----	4
2. Installation	-----	5
3. Caution and Maintenance	-----	6

# 1. Components



No.	Name
1	Oil cap
2	Pressure gauge
3	Regulator
4	Power switch
5	Drain lever
6	Hose connector
7	Regulator gauge
8	Dial
9	Air hose
10	Extra refrigeration oil

---

## 2. Installation

- **Please refer to the attached installation file**

## 3. Caution and Maintenance

- Turn off the compressor if the air is leaked every use
- Do not use the compressor for 7 minutes continually
- After using, close the air lever and turn off the compressor
- Do not tilt the compressor
- Drain with the lever every month
- Fill the refrigeration oil(SJ-27) 50cc in the intake every 3 ~ 4 months. The oil amount is up to the compressor usage.

---

### 3. Caution and Maintenance

- Turn off the compressor if the air is leaked every use
- Do not use the compressor for 7 minutes continually
- After using, close the air lever and turn off the compressor
- Do not tilt the compressor
- Drain with the lever every month
- Fill the refrigeration oil(SJ-27) 50cc in the intake every 3 ~ 4 months. The oil amount is up to the compressor usage.